



BOSCH

Cordless Screwdriver

PS21 | 3 601 J92 912

Table of Content

Spare parts list.....	2
Illustration - Type.....	3

Spare parts list

Item	Part Number	Description	Illustration
1	2 609 100 839	Housing BLUE	1
4	1 607 233 488	Electronics Module	1
5	2 609 100 825	Changeover Lever	1
9	2 610 007 737	Nameplate	1
20	2 609 100 826	Lens	1
32	2 609 199 279	Switchover Unit	1
45	2 606 200 259	Gear Box	1
70	2 609 110 537	Clip	1
91	1 607 A35 0C8	Battery Pack BAT 414 10,8/12V 2,0Ah	1
91	2 607 337 237	Battery Pack BAT 415 10,8V712V 2,5AH	1
101	2 609 110 883	Screw	1
653	2 607 225 139	Fast Charger USA/CAN 120/10,8-12V/30 MIN.	1
653	2 607 225 519	Fast Charger USA 120/3,6-10,8V,1h	1
802	2 610 014 489	DC motor	1
808	1 601 11A 6U9	Nameplate	1

Illustration - Type - E

3 601 J92 911
 Stand } 13-01-31
 Issue } **Fig./Abb. 1**

