



Parts List for PW18-B2 Type 1

| Item Number | Part Number | Description | Qty Required |
|-------------|-------------|----------------------|--------------|
| 1 | 5140136-96 | GUARD | 1 |
| 2 | 5140137-70 | CASING | 1 |
| 3 | 5140137-84 | KNOB | 1 |
| 4 | 5140137-89 | SWITCH | 1 |
| 5 | 5140138-32 | SUPPORT | 1 |
| 6 | 5140137-98 | SUCTION KIT | 1 |
| 7 | 5140137-92 | DELIVERY KIT | 1 |
| 8 | 5140138-51 | PUMP ASSEMBLY | 1 |
| 9 | 5140137-11 | BRUSH KIT | 1 |
| 10 | 5140125-97 | WATER COUPLING KIT | 1 |
| 11 | 5140136-99 | CONVEYOR | 1 |
| 12 | 5140137-00 | COVER | 1 |
| 13 | 5140138-23 | CASING | 1 |
| 14 | 5140138-40 | PLUG | 1 |
| 15 | 5140138-41 | TANK | 1 |
| 16 | 5140138-36 | NOZZLE CLEANING TOOL | 1 |
| 17 | 5140138-39 | LEVER | 1 |
| 18 | 5140138-37 | GREASE | 1 |
| 19 | 5140138-46 | WHEEL | 2 |
| 20 | 5140138-35 | BRACKET | 1 |
| 21 | 5140138-34 | BRACKET | 1 |
| 22 | 5140138-24 | BASE | 1 |
| 23 | 5140126-62 | CABLE | 1 |
| 24 | 5140137-05 | TSS KIT | 1 |
| 25 | 5140138-00 | PISTON SEAL KIT | 1 |
| 26 | 5140137-97 | WATER SEAL KIT | 1 |
| 27 | 5140138-02 | DETERGENT KIT | 1 |

Parts List for PW18-B2 Type 1

| Item Number | Part Number | Description | Qty Required |
|-------------|-------------|--------------------|--------------|
| 28 | 5140137-99 | SCREW KIT | 1 |
| 29 | 5140138-27 | BRACKET | 1 |
| 30 | 5140137-88 | HUB PIN | 2 |
| 31 | 5140137-74 | BRACKET | 1 |
| 32 | 5140137-77 | ACCESSORY HOLDER | 1 |
| 33 | 5140137-78 | ACCESSORY HOLDER | 1 |
| 34 | 5140137-73 | HANDLE | 1 |
| 35 | 5140126-63 | QUICK COUPLING | 1 |
| 101 | 5140137-42 | GUN | 1 |
| 102 | 5140137-50 | EXTENSION | 1 |
| 103 | 5140137-58 | LANCE HEAD | 1 |
| 104 | 5140137-10 | GASKET KIT | 1 |
| 105 | 5140138-55 | HIGH PRESSURE HOSE | 1 |