



R86211

KEY	P/N	DESCRIPTION	QTY	PIÈCE RÉF.	DESCRIPTION	QTÉ	REF. N/P	DESCRIPCIÓN	CANT.	
1	537505001	Forward/Reverse Selector	1	537505001	Interrupteur avant/arrière	1	1	537505001	Interruptor de adelante/atrás	1
2	206991001	Motor and Circuit Board Assembly (Inc. Key No. 21)	1	206991001	Ensemble moteur et carte de circuit imprimé (incl. pièce no. 21) ..	1	2	206991001	Conjunto de motor y de la placa de circuitos (incl. pza. núm. ref. 21)	1
3	691983001	Friction Ring	1	691983001	Anneau de friction	1	3	691983001	Anillo de fricción.....	1
4	204675007	Foot	1	204675007	Pied	1	4	204675007	Pie	1
5	661936005	Screw (M5 x 40 mm, T20 Torx Hd.).....	4	661936005	Vis (M5 x 40 mm, tête Torx T20).....	4	5	661936005	Tornillo (M5 x 40 mm, cabeza de Torx T20).....	4
6	660018005	Screw (M3.5 x 30 mm, T20 Torx Hd.).....	4	660018005	Vis (M3,5 x 30 mm, tête Torx T20)...	4	6	660018005	Tornillo (M3,5 x 30 mm, cabeza de Torx T20).....	4
7	360065002	End Cap	1	360065002	Capuchon d'extrémité.....	1	7	360065002	Tapa del extremo.....	1
8	204870002	Housing Assembly (Inc. Key No. 22-23)	1	204870002	Ensemble du boîtier (incl. pièces no. 22 et 23)	1	8	204870002	Conjunto de la armazón (incl. pzas. núms. ref. 22 y 23).....	1
9	570698001	O-Ring	1	570698001	Joint torique	1	9	570698001	Anillo "o"	1
10	941114115	Warning Label	1	941114115	Étiquette d'avertissement	1	10	941114115	Etiqueta de advertencia	1
11	660024051	Screw (M4 x 18 mm, T20 Torx Hd.).....	9	660024051	Vis (M4 x 18 mm, tête Torx T20).....	9	11	660024051	Tornillo (M4 x 18 mm, cabeza de Torx T20).....	9
12	307320046	Rear Gear Case.....	1	307320046	Carter d'engrenages arrière	1	12	307320046	Caja de engranajes trasero	1
13	565379001	Fiber Sealing Plate	1	565379001	Plaquette d'étanchéité en fibre	1	13	565379001	Placa de sellado de fibra.....	1
14	565296001	Oil Seal	1	565296001	Étanchéité d'huile.....	1	14	565296001	Sello de aceite.....	1
15	671436002	Pin	1	671436002	Goupille	1	15	671436002	Pasador	1
16	312029035	Hammer Assembly	1	312029035	Ensemble marteau	1	16	312029035	Conjunto del martillo	1
17	532700001	Washer	1	532700001	Rondelle	1	17	532700001	Arandela	1
18	643700001	Front Gear Case Assembly	1	643700001	Ensemble carter d'engrenages avant.....	1	18	643700001	Conjunto de caja de engranajes delantera	1
19	681773004	Ball	1	681773004	Bille.....	1	19	681773004	Bolas	1
20	621352206	Anvil.....	1	621352206	Enclume	1	20	621352206	Yunque	1
21	941001779	Control Panel Label.....	1	941001779	Étiquette de panneau de contrôle... 1	1	21	941001779	Etiqueta de panel de control.....	1
22	941122557	Data Label	1	941122557	Étiquette de données	1	22	941122557	Etiqueta de datos	1
23	941122558	Instruction Label.....	1	941122558	Étiquette d'instructions	1	23	941122558	Etiqueta de instrucciones.....	1

PAS ILLUSTRÉ :

998000070 Manuel d'utilisation

NOT SHOWN:


998000070 Operator's Manual

2-28-20

(Rev:02)

NO SE ILUSTRÁ:

998000070 Manual del operador



WIRING DIAGRAM / SCHÉMA DE CÂBLAGE / DIAGRAMA DE CABLEADO