


ELECTRIC TOOL PARTS LIST

■ **CORDLESS BLOWER**
Model RB 18DSL

2008·7·17
(E1)



PARTS

RB 18DSL

ITEM NO.	CODE NO.	DESCRIPTION	NO. USED	REMARKS
1		NAME PLATE	1	
2	328-557	PRINTED CIRCUIT BOARD	1	
3	328-558	DC-TRIGGER SWITCH (W/FELT)	1	
4	328-554	BATTERY HOLDER	1	
5	949-216	MACHINE SCREW M4X10 (10 PCS.)	2	
6	328-559	HOUSING (R)	1	
7	328-560	MOTOR HOLDER (B)	1	
8	328-615	MOTOR (W/SPINDLE)	1	
9	328-553	MOTOR HOLDER (A)	1	
10	328-563	MOTOR PLATE	1	
11	328-550	TAPPING SCREW D3.5X15	3	
12	328-564	FAN	1	
13	949-556	NUT M6 (10 PCS.)	1	
14	328-565	STRAP	1	
15	328-546	TAPPING SCREW D3.5X15 (BLACK)	8	
16	330-077	HOUSING (L)	1	
17	328-549	TAPPING SCREW D3.5X20 (BLACK)	1	
18		HITACHI LABEL	1	
19	328-562	NOZZLE	1	

OPTIONAL ACCESSORIES

RB 18DSL

ITEM NO.	CODE NO.	DESCRIPTION	NO. USED	REMARKS	
601	317-124	LONG NOZZLE ASS'Y	1	INCLUD. 602	
602	317-123	HOLDER	1		
603	990-046	NOZZLE (B)	1		
604	323-587	DUST BAG (DEEP BLUE)	1		