




# RD80702/RD80905 Gasoline Pressure Washer

KEY	P/N	DESCRIPTION	QTY	KEY	P/N	DESCRIPTION	QTY
1	661554001	Bolt (M8 x 45 mm, Hex Hd.).....	2	32	308937002	Left Frame .....	1
2	661554002	Bolt (M8 x 70 mm, Hex Hd.).....	2	33	518932001	Handle Tube Cap.....	2
3	661555001	Screw (M4 x 12.5 mm, Button Hd.).....	3	34	940786002	Trigger Handle Max Pressure Label .....	1
4	661555002	Screw (1/4-20 x 2.1 in., T30, Torx Hd.).....	1	35	940726009	Trigger Handle Label .....	1
5	660869005	Bolt (1/4-20 x 48.5 mm, Hex Hd.) .....	4	36	638680001	Logo Plate .....	1
6	661503001	Bolt (1/4-20 x 1 in.).....	2	37	638677002	Face Plate .....	1
7	661505003	Bolt (M8 x 50 mm).....	4	38	638385005	Engine Plate .....	1
8	661505005	Bolt (M8 x 36 mm, Hex Hd.).....	4	39	308936003	Hook Assembly (Inc. Key Nos. 9 and 18).....	1
9	660973013	Bolt (M8 x 67.15 mm, Hex Hd.).....	2	40	678406004	Connector Pin (1/4 in.).....	2
10	940971011	Hang Tag (Engine) .....	1	41	620505001	Axle .....	2
11	661556001	Screw (1/4-20 x 1.4 in., T30, Torx Truss Hd.) .....	4	42	678146002	Hitch Pin.....	2
12	661501001	Screw (1/4-20 x 1.85 in., Torx Hd.).....	1	43	308910001	Release Pin.....	1
13	120900031	Wand Holder Kit .....	1	44	308494004	Spray Wand.....	1
14	940617012	Quick Start Label (Engine).....	1	45	940654059	Low Oil Warning Label .....	1
15	940617050	Pump Quick Start Label .....	1	46	940778004	Hot Surface Label .....	1
16	661558001	Bolt (3/8-16 x 35 mm, Hex Hd.) .....	4	47	308710004	Wheel (12 in. x 4 in.).....	2
17	661557001	Bolt (5/16 x 19 mm, Hex Hd.).....	4	48	940726010	Performance Label.....	1
18	678774001	Lock Nut (M8 x 1.25).....	14	49	308235003	EX21 Engine (RD80702) .....	1
19	678016006	Lock Nut (1/4-20) .....	11		309591013	EX21 Engine (RD80905) .....	1
20	678610002	Lock Nut (M4).....	3	50	940599007	Data Label (RD80702) .....	1
21	638128004	Washer (1/4 in.).....	5		940599009	Data Label (RD80905) .....	1
22	940693003	Handle Release Label .....	1	51	940654058	Trigger Guard Warning Label (French/Spanish) .....	1
23	518724002	Washer (D20 x D18 x 4.5t).....	2	52	308692003	Garden Hose Coupler w/Filter.....	1
24	678600002	Washer (M4) .....	1	53	308988001	Quick Disconnect (Female 3/8 in.) .....	1
25	638128001	Washer (5/8 in.) .....	2	54	518954001	Trigger Handle Storage .....	1
26	638679001	Lock Washer (3/8 in.).....	4	55	518955002	Wand Holder .....	1
27	638678001	Lock Washer (5/16 in.).....	4	56	570554001	Wear Pad.....	2
28	638386002	Washer (3/8 in.).....	4	57	570712001	Rubber Bumper.....	1
29	638675002	Washer (5/16 in.).....	4	58	513122001	Auxiliary Handle Assembly .....	1
30	940654053	Warning Labels.....	1	59	638637002	Spring Clip.....	1
31	308938005	Right Frame Assembly (Inc. Key Nos. 3, 20, 24 and 57).....	1	60	570727002	Storage Holder.....	1
				61	308697007	Nozzle, 0° (Red).....	1
				62	308698007	Nozzle, 15° (Yellow).....	1
				63	308699007	Nozzle, 25° (Green).....	1
				64	308700007	Nozzle, 40° (White).....	1
				65	308835002	High Pressure Hose.....	1
				66	561399003	Injection Hose .....	1
				67	518391001	Injection Hose Filter .....	1
				68	308662001	Filter Screen .....	1
				69	310660005	Dual Power Soap Nozzle.....	1
				70	310664001	Bungee Cord and Bead Assembly .....	1
				71	308940001	Handle Assembly (Inc. Key No. 33).....	1
				72	308909002	Foot Assembly .....	2
				73	940778005	Hot Muffler Label.....	1
				74	120950013	Trigger Handle Assembly .....	1
				75	308694006	Pump (Inc. Key Nos. 16-17, 26-29 and 78)....	1
				76	570733002	Handle Bumper .....	2
				77	678169004	Thermal Relief Valve.....	1
				78	310735001	Chemical Injector .....	1
				79	940654061	Trigger Guard Warning Label (English).....	1
				80	678024002	Wrench (T30 Torx) .....	1
				81	660738001	Bolt (1/4 in., Hex Hd.).....	1
				82	940716002	Vent Cap Label.....	1
					<b>Not Shown:</b>		
					*	Oil (SAE 30 or SAE 10W30).....	1
					940971048	Hang Tag (EFI Oil Bottle) .....	1
					987000274	Operator's Manual.....	1
					987000275	Replacement Parts List .....	1
					987000276	Assembly Guide .....	1





# RD80702/RD80905 Pump/Pompe/Bomba

KEY	P/N	DESCRIPTION	QTY	PIÈCE RÉF.	DESCRIPTION	QTÉ	REF.	N/P	DESCRIPCIÓN	CANT.
1	310733003	Oil Fill Cap w/O-ring.....	1	310733003	Capuchon, orifice de remplissage d'huile, avec joint torique.....	1	1	310733003	Tapa, orificio de llenado para aceite con junta tórica .....	1
2	308688006	Gauge .....	1				2	308688006	Escala.....	1
3	120440001	Seal Kit (Inc. Key Nos. 4-8).....	1	2	308688006	Jauge .....	3	120440001	Kit del sello (incl. pzas. núms. ref. 4 a 8) .....	1
4	308405004	Adapter (Male).....	3	3	120440001	Kit de joint (incl. pièces no. 4 à 8) .....	4	308405004	Adaptador (macho) .....	3
5	570436001	V-Packing.....	3	4	308405004	Adaptateur (mâle).....	5	570436001	Embalaje de labios múltiples .....	3
6	570742004	Seal Case O-Ring .....	3	5	570436001	Garniture chevron .....	6	570742004	Junta tórica, estuche para sellos .....	3
7	570763004	Seal .....	3	6	570742004	Joint torique carter de joint d'étanchéité .....	7	570763004	Sello .....	3
8	570435001	Washer (Seal) .....	3	7	570763004	Joint d'étanchéité .....	8	570435001	Arandela (sello).....	3
9	120441001	Valve Assembly (Inc. Key Nos. 10-19) .....	1	8	570435001	Rondelle (joint d'étanchéité) .....	9	120441001	Conjunto de válvula (incl. pzas. núms. ref. 10 a 19) .....	1
10	570742007	O-Ring (Plug).....	3	9	120441001	Ensemble de soupape (incl. pièces no. 10 à 19) .....	10	570742007	Junta tórica, clavija .....	3
11	521407001	Spring Retainer .....	3	10	570742007	Joint torique, bouchon.....	11	521407001	Retén de resorte .....	3
12	678519005	Spring.....	6	11	521407001	Retenue de ressort.....	12	678519005	Resorte.....	6
13	678169008	Valve.....	6	12	678519005	Ressort.....	13	678169008	Válvula.....	6
14	310402001	Discharge Seat.....	3	13	678169008	Soupape.....	14	310402001	Asiento de descarga .....	3
15	570742006	O-Ring (Discharge Seat) .....	3	14	310402001	Assise de refoulement.....	15	570742006	Junta tórica, asiento de descarga.....	3
16	521409001	O-Ring (Discharge Seat) .....	3	15	570742006	Joint torique, assise de refoulement..	16	521409001	Junta tórica, asiento de descarga.....	3
17	521406001	Spring Retainer (Inlet).....	3	16	521409001	Joint torique, assise de refoulement..	17	521406001	Retén de resorte (entrada) .....	3
18	521408001	Inlet Seat .....	3	17	521406001	Retenue de ressort (admission) .....	18	521408001	Asiento, entrada.....	3
19	570742005	O-Ring (Inlet Seat).....	3	18	521408001	Assise, admission .....	19	570742005	Junta tórica, asiento de entrada .....	3
20	678842001	Check Valve Seat .....	1	19	570742005	Joint torique, assise d'admission .....	20	678842001	Asiento, válvula de retención .....	1
21	308826003	Valve.....	1	20	678842001	Assise, clapet antiretour .....	21	308826003	Válvula, control con junta tórica.....	1
22	120442001	O-Ring Kit (Inc. Key Nos. 23-28).....	1	21	308826003	Valve, clapet antiretour avec joint torique .....	22	120442001	Juego, junta tórica (incl. pzas. núms. ref. 23 a 28) .....	1
23	570742010	O-Ring (Piston Retainer) .....	2	22	120442001	Ensemble, joint torique (incl. pièces no. 23 à 28) .....	23	570742010	Retén de pistón (junta tórica).....	2
24	310403001	Back-up-Ring (Piston Stem) .....	1	23	570742010	Retenue de piston (joint torique).....	24	310403001	Anillo de respaldo vástago del pistón.....	1
25	570742008	O-Ring (Piston Stem) .....	1	24	310403001	Bague d'appui, tige de piston.....	25	570742008	Junta tórica, vástago del pistón.....	1
26	570742011	O-Ring (Inner Valve Retainer).....	1	25	570742008	Joint torique, tige de piston .....	26	570742011	Junta tórica, retén de válvula (interior) .....	1
27	570742009	O-Ring (Outer).....	1	26	570742011	Joint torique, coupelle d'appui de soupape (interne) .....	27	570742009	Junta tórica, retén de válvula (exterior).....	1
28	570742012	Seat O-Ring .....	2	27	570742009	Joint torique, coupelle d'appui de soupape (extérieure) .....	28	570742012	Asiente el anillo o .....	2
29	310735002	Fixed Injector (M18 x 1 mm) .....	1	28	570742012	Posez le joint circulaire .....	29	310735002	Fuego de inyector fijo (M18 x 1 mm) ..	1
30	310923001	Drain Plug .....	1	29	310735002	Fixe d'injecteur (M18 x 1 mm).....	30	310923001	Tapón de drenaje .....	1
31	679405002	Plug .....	3	30	310923001	Bouchon de vidange.....	31	679405002	Tapón .....	3
32	570742070	O-Ring.....	1	31	679405002	Bouchon.....	32	570742070	Anillo en "O".....	1
33	570742069	Oil Seal.....	1	32	570742070	Joint torique en O .....	33	570742069	Aceite el sello .....	1
34	570763007	Oil Seal.....	1	33	570742069	Joint d'huile.....	34	570763007	Aceite el sello .....	1
35	310924001	Unloader Assembly (Inc. Key No. 22) 1	1	34	570763007	Joint d'huile.....	35	310924001	Conjunto del descargador (incl. pza. núm. ref. 22).....	1
	<b>NOT SHOWN</b>			35	310924001	Ensemble déchargeur (incl. pièce réf. 22).....				
	900906018	Bottle Oil .....	1							
					<b>PAS ILLUSTRÉ</b>			<b>NO SE MUESTRA</b>		
					900906018	Bouteille d'huile.....		900906018	Aceite en botella .....	1