


H Husqvarna



Royal 53 S/SE



1.1992

Spare parts

Ersatzteile


Pièces détachées

Reserve onderdelen

Repuestos


Reservdelar




A





C


NORTH AMERICA ONLY







F



PARTNUMBER	SQUARE	PARTNUMBER	SQUARE	PARTNUMBER	SQUARE
515 11 70-01	D	516 80 71-01	F	516 92 47-01	A
515 13 10-64	D	516 80 74-53	G	516 92 48-01	A
515 13 97-65	F	516 82 31-02	B	516 92 49-01	A
515 71 16-30	F	516 82 38-09	E	516 92 51-00	B,C
515 72 46-35	B	516 82 43-00	B,C	516 92 52-01	F
515 74 50-46	A	516 82 45-00	B,C	516 92 79-00	F
515 79 60-01	D	516 82 49-00	E	516 92 80-01	G
515 79 60-33	F	516 82 50-00	B,C	721 42 10-00	F
516 42 62-01	F	516 82 71-00	C	721 43 12-00	F
516 42 97-01	F	516 82 76-00	C	725 24 50-51	A,B
516 43 05-07	B	516 82 77-00	C	725 24 59-51	B
516 43 21-01	B	516 83 25-00	B,C	725 24 97-71	F
516 44 02-01	B	516 83 45-00	D	725 54 64-01	D
516 44 06-01	B	516 83 53-08	E	727 64 59-01	B,C
516 44 07-01	F	516 83 64-07	F	727 64 61-01	B
516 44 14-01	F	516 83 71-11	B	728 84 45-01	D
516 44 62-00	D	516 84 11-00	A	732 21 16-01	B,C,F
516 44 77-01	F	516 84 20-00	D	732 21 16-21	B
516 44 91-01	A	516 84 21-00	F	732 21 18-01	A,B,D
516 44 96-01	F	516 84 41-00	H	732 21 20-01	F
516 47 79-00	D	516 84 43-00	H	732 21 20-31	E
516 47 97-00	D	516 84 44-00	B,H	734 11 64-41	A,B,F
516 49 02-01	A	516 84 45-09	H	735 11 73-01	F
516 49 10-01	C	516 84 46-00	H	738 21 03-04	F
516 49 19-01	F	516 84 57-09	E		
516 49 20-01	F	516 84 58-08	E		
516 49 22-01	F	516 84 62-07	A		
516 49 23-01	A	516 84 73-11	B,C		
516 49 27-01	A	516 84 80-07	A		
516 49 43-04	D	516 84 81-07	A		
516 49 47-01	F	516 84 82-11	C		
516 49 48-11	E	516 84 83-00	C		
516 49 49-11	E	516 84 84-11	B,C		
516 49 50-01	F	516 84 88-11	A		
516 49 51-01	F	516 84 89-11	A		
516 49 66-11	F	516 85 04-11	A		
516 49 71-11	B	516 85 05-11	A		
516 49 72-11	B	516 85 08-09	F		
516 49 92-01	F	516 85 13-11	G		
516 49 95-01	A	516 85 20-10	D		
516 50 96-01	A	516 85 22-00	A		
516 51 05-01	D	516 85 29-00	H		
516 51 06-01	D	516 85 50-00	A		
516 51 07-01	D	516 85 57-97	B,C		
516 51 12-11	A	516 85 70-07	B		
516 60 79-01	D	516 85 89-11	B		
516 61 23-11	B	516 86 47-07	B,C		
516 61 25-01	B	516 86 47-15	B,C		
516 61 29-01	A	516 86 49-00	G		
516 61 40-01	F	516 90 51-00	F		
516 61 42-01	F	516 90 84-00	F		
516 61 43-11	A	516 90 90-01	F		
516 61 44-11	A	516 90 97-00	F		
516 61 46-01	E	516 91 00-00	E		
516 61 48-01	E	516 91 14-00	D		
516 69 37-00	F	516 91 28-00	A		
516 70 02-07	C	516 91 62-01	F		
516 70 03-07	C	516 92 06-02	F		
516 70 05-01	F	516 92 12-00	D		
516 70 12-11	D	516 92 15-00	E		
516 70 25-07	B	516 92 16-00	E		
516 70 27-11	A	516 92 20-00	F		
516 70 31-00	F	516 92 21-00	F		
516 70 42-07	B	516 92 27-01	C		
516 70 80-11	G	516 92 41-01	D		
516 70 85-01	A	516 92 42-01	F		
516 70 87-01	F	516 92 44-00	A		
516 70 88-01	F	516 92 45-00	D		
516 80 58-00	F	516 92 46-00	F		