


SANDER

RS-115

~~XXXXXXXXXXXXXXXXXXXX~~
~~XXXXXXXXXXXXXXXXXXXX~~



has a

768 333 005
 Hook & Loop

Buckin Pad

43700

**PARTS LIST FOR AFTER SALES SERVICE
 MODEL RS115**

REF	PART NO.	DESCRIPTION	QTY	REF	PART NO.	DESCRIPTION	QTY
1	663570001	LOGO PLATE	1				
2	970113000	HOUSING ASSEMBLY	1				
3	623019004	RUBBER PLUG	1				
4	968303018	SWITCH	1				
5	968304013	BRUSH ASSEMBLY	2				
6	622274001	BALL BEARING 608ZZ	1				
7	968307028	FIELD	1				
8	968306022	ARMATURE	1				
9	622167014	RETAINING RING	1				
10	968645001	FRONT KNOB ASSEMBLY	1				
11	968700011	SCREW	7				
12	663869001	DATA PLATE	1				
13	623552003	* SANDING DISC	1				
14	969849001	SCREW	1				
15	968347001	WASHER	1				
16	998588001	SCREW	4				
17	968333001	RACKING PAD	1				
18	968305012	BEARING CAP W/ BEARING	1				
19	968336001	FAN	1				
20	941401834	ROLL PIN	1				
21	969235004	BALL BEARING #6002LLU	1				
22	969533002	DUST BOX	1				
23	967917001	CORD CLAMP	1				
24	969274013	CORD	1				
25	968602001	BEND RELIEF	1				
26	969421007	LEAD	1				
27	970099001	SEAL	1				
28	999186001	BRUSH TUBE	2				
29	623552003	STATOR PAD	1				
30	968775001	SCREW	2				
31	990133001	SLEEVE BEARING	1				

* SEE CATALOG FOR ASSORTMENT

SERVICE NOTES:

