


RYOBI RANDOM ORBIT SANDER – MODEL NUMBER RS280VS



WARNING: Improper repair of a double insulated tool can result in damages to the double insulation system possibly causing electrical shock or electrocution. Any repairs requiring disassembly of your tool requires safety testing and should only be performed by a Ryobi Authorized Service Center. For the service center nearest you call 1-800-525-2579.

RYOBI RANDOM ORBIT SANDER – MODEL NUMBER RS280VS

The model number will be found on a plate attached to the motor housing. Always mention the model number in all correspondence regarding your **RANDOM ORBIT SANDER** or when ordering repair parts.

PARTS LIST

KEY NO.	PART NUMBER	DESCRIPTION	QTY.
1	643526-003	* SCREW (8-18 X 5/8 in. PAN HD.)	3
2	5926801	TOP CAP	1
3	7622701	SWITCH	1
4	982308-001	ACTUATOR	1
5	2913502	BLACK LEAD	1
6	2913501	BROWN LEAD	1
7	3077101	CIRCUIT BOARD ASSEMBLY	1
8	2907514	BRUSH ASSEMBLY	1
9	623019-004	RUBBER PLUG	1
10	3014115	HOUSING ASSEMBLY	1
11	9429802	LOGO LABEL	1
12	5926901	SPACER	1
13	931744-828	WASHER	1
14	622183-026	* SCREW (8-32 X 1/2 in. FLAT HD.)	1
15	3052701	DISC ASSEMBLY	1
16	300552012	SANDPAPER	1
17	998586-001	* SCREW (10-32 X 1/4 in. PAN HD.)	4
18	3054605	BEARING CAP ASSEMBLY	1
19	5524801	BRAKE/SKIRT	1
20	6405201	FAN/COUNTERBALANCE	1
21	2910602	ARMATURE ASSEMBLY	1
22	990908-009	* SCREW (6-19 X 5/8 in. PAN HD.)	2
23	623552-004	STATOR PAD	1
24	2910502	FIELD ASSEMBLY WITH LEADS	1
25	9429801	DATA PLATE	1
26	990908-008	* SCREW (6-19 X 9/16 in. PAN HD.)	2
27	6947301	ACTUATOR SPRING	1
28	7321601	POWER CORD	1
29	623173-007	WIRE NUT	2
30	975244-003	DUST BAG ASSEMBLY	1
31	974484-001	CONVERSION PAD	1
	983000-128	OPERATOR'S MANUAL	
	983000-128R	REPAIR SHEET	
	12-04-03		

*** Standard Hardware Item – May Be Purchased Locally**