

RYOBI BLOWER/VACUUM - MODEL NUMBERS RY09050




Figure A

RYOBI BLOWER/VACUUM – MODEL NUMBERS RY09050

The model number will be found on a label attached to the starter housing. Always mention the model number in all correspondence regarding your **BLOWER/VACUUM** or when ordering repair parts.

PARTS LIST (FIGURE A)

KEY NO.	PART NUMBER	DESCRIPTION	QTY
1	900960001	Vacuum Bag w/Shoulder Strap.....	1
2	570543001	Upper Blower Tube	1
3	580613001	High Velocity Nozzle w/Leaf Scraper.....	1
4	580537001	Sweeper Nozzle	1
5	570563001	Vacuum Bag Adaptor.....	1
6	570562001	Lower Vacuum Tube	1
7	660621001	Vacuum Tube Screw (10-14 x 1/2 In.).....	4
8	580892001	Upper Vacuum Tube	1
9	660880001	Screw (1/4-20 x 3/4 In.).....	2
10	521500001	Vacuum Door	1
11	650027001	E-Ring	2
12	678726001	Vacuum Door Spring.....	1
13	870174001	* Spark Plug (RCJ6Y)	1
14	310804001	Air Filter Cover	1
15	560873003	Filter	1
16	310816001	Fuel Cap Assembly.....	1
17	521504001	Vacuum Handle.....	1
18	570107001	Air Box Gasket.....	1
	Not Shown:		
	940835001	Run/Start Label.....	1
	940734062	Starting Label.....	1
	940657039	Warning Label.....	1
	940752006	Logo Label (Small)	1
	940705075	Logo Label (Large)	1
	940654088	Combustion Label.....	1
	987000868	Operator's Manual (960413003).....	1
	11-6-09 (REV:01)		

* STANDARD HARDWARE ITEM – MAY BE PURCHASED LOCALLY

RYOBI BLOWER/VACUUM - MODEL NUMBERS RY09050




Figure B

RYOBI BLOWER/VACUUM – MODEL NUMBERS RY09050

The model number will be found on a label attached to the starter housing. Always mention the model number in all correspondence regarding your **BLOWER/VACUUM** or when ordering repair parts.

PARTS LIST (FIGURE B)

KEY NO.	PART NUMBER	DESCRIPTION	QTY	KEY NO.	PART NUMBER	DESCRIPTION	QTY
1	660629002	Screw (10-14 x 3/4 in.).....	9	29	521316001	Starter Pulley	1
2	521313001	Outer Volute	1	30	638389001	Pulley Retainer.....	3
3	660730001	Lock Nut (3/8 in.)	1	31	660967001	Screw (M4 x 14 mm, T.F.).....	3
4	650016001	Washer	2	32	650017001	Washer.....	1
5	521308001	Fan	1	33	308674001	Rotor and Pawl Assembly	1
6	638091008	Spacer	1	34	309963001	Short Block Assembly	1
7	660970001	Screw (M4 x 17 mm, T.F.).....	4	35	308461001	Engine Cover	1
8	660666001	Screw (8-14 x 1 in., T.F.).....	1	36	901362002	Muffler Gasket	1
9	678125001	Washer.....	1	37	309327001	Muffler Assembly	1
10	518160001	Cruise Lever.....	1	38	638442009	Muffler Heat Shield	1
11	308981013	Lower Housing	1	39	660638003	Screw (10-24 x 2-1/8 in.)	2
12	518603001	Throttle Lever.....	1	40	660927004	Screw (10-24 x 2.5 in.).....	2
13	661141001	Screw (M3.5 x 7.5 mm).....	1	41	518920001	Heat Dam.....	1
14	521503001	Throttle Trigger	1	42	638659002	Washer.....	2
15	518602001	Trigger Lock.....	1	43	660927003	Screw (M5 x 25 mm).....	2
16	760338004	Momentary Contact Switch.....	1	44	521505001	Baffle.....	1
17	290157002	Wire Assembly.....	1	45	901552002	Heat Dam Gasket	2
18	270031002	Throttle Cable	1	46	308054025	Carburetor	1
19	521501001	Handle Cover	1	47	521309001	Air Box Base.....	1
20	660466001	Screw (M4 x 18 mm).....	5	48	678027001	Hex Nut (10-24)	2
21	660968001	Screw (M4 x 19 mm, T.F.).....	2	49	901550001	Crankcase Cover Gasket.....	1
22	850108006	Ignition Module.....	1	50	638337001	Crankcase Cover	1
23	308563001	Lower Housing w/Starter.....	1	51	660925003	Screw (M4 x 12 mm).....	6
24	900849012	Starter Rope (42 in.).....	1	52	660970002	Screw (M4 x 16 mm).....	3
25	511731001	Starter Grip	1	53	310752001	Fuel Tank Assembly w/Cap	1
26	638088004	Eyelet.....	1	54	518842001	Choke Lever	1
27	521535001	Shield.....	1	55	561635001	Primer Bulb.....	1
28	638033001	Spring & Container	1	56	290469001	Ground Wire Kit	1