



RYOBI

9.6V/12V CORDLESS DRILL KIT

MODEL NO. RY961K2B/RY1201K2B

REPAIR SHEET

9.6V/12V CORDLESS DRILL KIT RY961K2B/R Y1201K2B



PARTS LIST FOR AFTER SALES SERVICE

MODELS RY961K2B/RY1201K2B

REF	PART NO.	DESCRIPTION	QTY	REF	PART NO.	DESCRIPTION	QTY
					STANDARD ACCESSORIES		
1	1130049	SCREW M5X0.8X26MM	1				
2	974430001	KEYLESS 3/8 CHUCK	1	501	1400651	BATTERY PACK-RY961K2B	2
3	1130302	SCREW M3X14	4		1400652	BATTERY PACK-RY1201K2B	2
4	4900094	MOUNTING PLATE	1	502	4240014	DOUBLE BIT PH #2/SLOT#6	1
5	1290021	STEEL BALL 3MM	8	503	4240015	DOUBLE BIT PH #3/SLOT#7	1
6	4190002	BALL HOLDER, PLASTIC	1	510	981351001	CHARGER ASSY RY961K2B	1
7	4900095	WASHER	1		981351002	CHARGER ASSY RY1201K2B	1
8	4900096	CLUTCH CAP	1	512	1770027	NYLON BAG	1
9	4180026	SPRING PLATE	2				
10	4900097	PLASTIC SLEEVE	1		972000570	OPERATOR'S MANUAL	1
11	4180030	TORQUE SPRING	1				
12	4360009	LOCATION CUP, PLASTIC	1				
13	4360006	BIT HOLDER, PLASTIC	1				
14	4900099	CLUTCH WASHER	1				
15	4900104	STAINLESS WASHER	1				
16	4950034	LEVELLER ASSY	1				
17	4800038	HOUSING-RY961K2B	1				
	4800039	HOUSING-RY1201K2B					
18	4750013	BALL,STEEL 4.0MM	16				
19	4050010	GEAR BOX	1				
20	4030014	MOTOR ASSY-RY961K2B	1				
	4030015	MOTOR ASSY-RY1201K2B	1				
21	1130050	STEEL M3X8MM	1				
22	4900103	SPRING WASHER	1				
23	4590010	HEAT SINK	1				
24	4130280	STEEL HEX NUT	1				
25	4550043	SWITCH ASSY RY961K2B	1				
	4550044	SWITCH ASSY RY1201K2B	1				
26	4560028	PLATE HOLDER ASSY	1				
27	1130304	SET SCREW M3.5X16MM	8				
28	4910047	RATING LABEL-RY961K2B	1				
	4910049	RATING LABEL-RY1201K2B	1				
29	4910048	BRAND LABEL-RY961K2B	1				
	4910050	BRAND LABEL-RY1201K2B	1				

SERVICE NOTES