

RYOBI
13 in. LAWN MOWER
ITEM NO. RYAC130
MFG NO. 099749004
REPAIR SHEET


Techtronic Industries Power Equipment

1428 Pearman Dairy Road, Anderson, SC 29625

Phone 1-800-860-4050

www.ryobitools.com

RYOBI LAWN MOWER – ITEM NO. RYAC130



RYOBI LAWN MOWER – ITEM NO. RYAC130

The model number will be found on a label attached to the deck. Always mention the model number in all correspondence regarding your **LAWN MOWER** or when ordering replacement parts.

FIGURE A PARTS LIST

Key Part No. Number	Description	Qty	Key Part No. Number	Description	Qty
1	099749004001 Screw (M4 x 8 mm).....	2	22	099749004022 Deck Cover	1
2	099749004002 Control Box Assembly	1	23	099749004023 Grass Protector (Right)	1
3	099749004003 Power Lever.....	1	24	099749004024 Counter Weight.....	1
4	099749004004 Upper Handle Assembly.....	1	25	099749004025 Grass Protector (Left).....	1
5	099749004005 Lower Cover (Control Assembly).....	1	26	099749004026 Metal Cap	4
6	099749004006 Screw (M4.2 x 15 mm).....	33	27	099749004027 Air Inlet (Right)	1
7	099749004007 Bale Handle Cover (Right)	1	28	099749004028 Foam.....	2
8	099749004008 Bale Handle Holder.....	1	29	099749004029 Rear Wheel	2
9	099749004009 Bale Handle Cover (Left).....	1	30	099749004030 Deck.....	1
10	099749004010 Cord Clamp	1	31	099749004031 Foam.....	1
11	099749004011 Screw w/Washer (M3 x 16 mm).....	2	32	099749004032 Front Wheel.....	2
12	099749004012 Knob	2	33	099749004033 Front Wheel Axle.....	1
13	099749004013 Bolt (M6 x 50 mm)	2	34	099749004034 Axle Pressure Plate.....	4
14	099749004014 Cord Clamp	1	35	099749004035 Blade Holder	1
15	099749004015 Lower Handle.....	1	36	099749004036 Blade.....	1
16	099749004016 Handle Height Adjustment Button.....	2	37	099749004037 Hex Nut (M10, Flange).....	1
17	099749004017 Torsion Spring (Height Adjustment).....	2	38	099749004038 Height Adjustment Lever Assembly	1
18	099749004018 Spring Pin	2	39	099749004039 Lock Pin.....	2
19	099749004019 Button Support	1	40	099749004040 Lock Pin Seat.....	2
20	099749004020 Handle.....	1	41	099749004041 Front Lift Rod.....	1
21	099749004021 Motor Cover.....	1	42	099749004042 Foam.....	1


RYOBI LAWN MOWER – ITEM NO. RYAC130

The model number will be found on a label attached to the deck. Always mention the model number in all correspondence regarding your **LAWN MOWER** or when ordering replacement parts.

FIGURE A PARTS LIST

Key Part No. Number	Description	Qty	Key Part No. Number	Description	Qty
43	099749004043 Cord Clamp	1	64	099749004065 Bag Cover Plug (Right)	1
44	099749004044 Rear Skirt	1	65	099749004066 Button Support	1
45	099749004045 Rear Skirt Plate.....	1	66	099749004067 Bag Cover.....	1
46	099749004046 Bearing 6902Z	1	67	099749004068 Handle.....	1
47	099749004047 Screw (M4.2 x 18 mm).....	7	68	099749004069 Bag Indicator	1
48	099749004048 Motor	1	69	099749004070 Bag	1
49	099749004050 Dust Proof Motor Cover.....	2	70	099749004071 Bag Cover Plug (Left).....	1
50	099749004051 Rear Discharge Door	1	71	940657270 Side Warning Label.....	1
51	099749004052 Mulching Plug	1	72	940657269 Waring Icon Label	1
52	099749004053 Rear Cover.....	1	73	940705383 Front Logo Label.....	1
53	099749004054 Rear Wheel Axle	1	74	940851277 Height Adjustment Label	1
54	099749004055 Rear Lift Rod.....	1	75	940851278 Feature Label	1
55	099749004056 Screw (M4.2 x 12 mm).....	3	76	940851279 Feature Label	1
56	099749004057 Screw w/Washer (M4.8 x 18 mm).....	1	77	941641001 Danger Label	1
57	099749004058 Retention Spring.....	1	78	941588166 Data Label.....	1
58	099749004059 Air Inlet (Left).....	1		Not Shown:	
59	099749004060 Axle Bracket.....	1		099749004049 Belt	
60	099749004061 E-Ring	2		995000157 Operator's Manual	
61	099749004062 Rear Door Axle.....	1		10-13-17	
62	099749004063 Torsion Spring (Rear Door).....	1		(Rev:02)	
63	099749004064 Bag Frame	1			

RYOBI LAWN MOWER – ITEM NO. RYAC130



WIRING DIAGRAM