


Rider 850-8/12



1. 1989
Spare parts
Ersatzteile
Pièces détachées
Reserve onderdelen
Repuestos
Reservdelar

A

* compl 506 56 62-01

* 722 78 39-00

* 506 54 56-01

* 506 57 44-01

506 57 01-05

506 67 21-01

506 67 55-01

506 54 77-01

506 66 79-01 (12 hp)

731 323 18-01

723 23 66-31

506 58 94-01

506 55 97-01

722 79 81-02

722 79 44-02

506 66 78-01 (12 hp)

506 59 48-01 (12 hp)

734 11 36-41

722 79 44-02

506 59 73-01 (12hp)

compl 506 59 52-01 (12hp)

506 55 36-01

734 11 46-01

732 21 14-01

compl 506 59 97-01

506 56 93-01

506 55 97-01

506 66 22-01

506 59 67-02

725 23 64-51

734 11 53-01

506 56 92-01


506 66 22-02

506 59 67-01

722 79 44-02

506 66 97-01S,F

734 11 36-01



B

* compl 506 67 02-01 (12hp)

* 506 67 33-01

* 506 57 62-01

734 11 53-01
725 23 66-51
725 24 49-51

506 67 03-01
732 21 18-01

735 31 40-10
738 21 05-04

506 66 73-01
506 76 08-01 U.S., Ca.
506 58 52-01
506 54 49-01

506 59 75-01
506 55 60-02 U.S., Ca.
506 55 60-01
506 66 03-01
731 23 16-01

506 57 64-01

506 67 01-01 *
506 66 41-01
506 66 40-01 *
506 66 42-01

733 79 74-40

729 54 48-02
506 66 36-01 (12hp)


731 23 18-01

506 59 34-01
506 66 88-01
506 50 99-01
735 31 12-01

721 68 02-51
725 24 53-51

506 57 63-01
506 67 19-01
506 67 08-01
732 21 18-01

725 23 70-51
506 66 45-01
731 23 20-51



506 59 20-01






728 74 55-05
506 59 43-01
506 59 43-02 D

506 59 46-01
506 57 01-03

729 53 29-71
506 53 87-01
506 53 86-01
735 58 35-01
725 23 64-61
506 53 85-01

506 53 89-01
506 53 88-01
735 58 35-01
506 55 17-01


734 11 46-01
723 13 27-51
506 54 61-01




C

**Correction:
506 50 35-01**

* compl 506 5035-01



D




E

Husqvarna 506 66 11-01

Husqvarna 506 57 11-01


 506 66 27-01

506 66 10-02
506 66 10-04 (12hp)



725 23 29-51
734 11 46-01
506 55 07-01
506 55 86-01
731 23 14-01
734 11 46-01
506 55 06-01

506 59 96-01
506 59 95-01



F

(12 hp)

506 59 56-01
506 66 34-01
506 66 85-01
506 67 22-01

506 67 16-01
506 66 82-01
506 59 24-01
506 54 92-01

729 54 48-02
506 54 93-01
506 55 82-01

506 53 51-01
506 55 83-01

734 11 46-01
731 23 14-01
725 23 27-51
731 23 18-01
506 55 59-01

506 66 83-01
506 58 82-01
506 66 84-01

(12 hp)


725 24 49-51
506 51 75-01
506 56 61-01
506 55 81-01
506 55 81-01
506 51 76-01

506 54 79-01
722 78 70-03
725 24 49-51


506 58 30-01 (12 hp)
506 59 58-01
731 23 18-01
506 67 51-01 (12 hp)
506 55 58-01

725 24 57-51

734 11 64-01
731 23 18-01
506 50 92-01




G




H

compl 506 56 04-01



compl 506 56 04-02 US, Ca






* compl 506 53 34-01 Yttre. Outer. Exterieur. Ausser. Ulko.
 * compl 506 53 34-02 Mitten. Center. Centre. Zentrum. Keski


K




L




506 53 39-01
506 53 24-01




M











P



R



* compl 964 99 55-01