


RYOBI POWER PAINT SPRAYER TOOL - MODEL NUMBER SSP200



RYOBI POWER PAINT SPRAYER TOOL – MODEL NUMBER SSP200

The model number will be found on a label attached to the housing assembly. Always mention the model number in all correspondence regarding your **POWER PAINT SPRAYER TOOL** or when ordering parts.

PARTS LIST

KEY NO.	PART NUMBER	DESCRIPTION	QTY	KEY NO.	PART NUMBER	DESCRIPTION	QTY
1	660272001	Screw (M4 x 14 mm)	2	27	519454001	Pump Housing Holder.....	1
2	5950101	Cord Clamp	1	28	680022004	Hex Nut (M4 x 3.2 mm)	4
3	560141002	Bend Relief.....	1	29	660414008	Screw (M4 x 16 mm, T-20 Torx Pan Hd.).....	1
4	940032130	Data Label.....	1	30	660024044	Screw (M4 x 16 mm, T-20 Pan Hd.)	2
5	303428002	Hook Assembly	1	31	220110004	Gear Box Assembly.....	1
6	672324001	Location Pin	1	32	660414014	Screw (M4 x 20 mm, T-20 Torx Pan Hd.).....	2
7	692333001	Compression Spring	1	33	660414015	Screw (M4 x 14 mm)	1
8	660208052	Screw (M4 x 16 mm)	13	34	692397001	External Toothed Lock Washer	1
9	940221113	Warning Label (French)	1	35	670030009	Washer (OD7.2 x ID4.1 x 1t).....	2
10	680611001	Washer (OD8 x ID5.2 x 1.2t).....	1	36	200300040	Switch Assembly.....	1
11	692350001	Retaining Ring.....	1	37	730377034	Power Cord	1
12	220163033	Housing Assembly	1	38	671502001	Finger Disc Spring (22 mm).....	1
13	940221114	Warning Label (Spanish)	1	39	230278004	Motor & Pinion Assembly.....	1
14	961007022	Hang Tag Label	1	40	303263001	Cleaning Brush Assembly	1
15	521789001	Suction Mesh Set.....	1	41	940221100	Warning Label (English).....	1
16	521788001	Suction Tube	1	42	940114157	Logo Label	1
17	562549002	Paint Hose.....	1	43	201144003	1.5 Qt. Container (Inc. Key No. 19)	1
18	201144001	1 Qt. Container (Inc. Key No. 19)	1	44	303837001	Container Cap (1.5 Qt.)	1
19	560159001	O-Ring	2	45	902277001	Felt Seal	1
20	303262002	Spray Round Tip Assembly.....	1	Not Shown:			
21	303970003	Wide Angle Tip Assembly	1	902472001	Tool Bag	1	
22	303265001	Swirl Valve Assembly	1	902332001	Lubricant Oil.....	1	
23	519459001	Locking Nut.....	1	988000023	How To Get Started Flyer.....	1	
24	303221001	Pump Housing Assembly.....	1	988000022	Operator's Manual		
25	692331001	Compression Spring	1	1-17-12			
26	303233002	Piston Assembly.....	1	(Rev:03)			