


Parts Catalog

Trimmer/Brushcutter


Model: TBC-202

Units Prior To Serial No. F005800

TBC-205 OPTIONS AND ACCESSORIES










.

	NBR PARNER	at ste	STY SERIANER REMARKS
1-002	157-04000-900	SPARK PLUG CAP ASS'Y	St SER NU REF.
1-003 1-004 1-004	002-0632R-800	SPARK PLUG BN6A Cylinder Comp. Cylinder Comp.	1 1 R -C219219 1 R -D131490
1-004 1-005		CYLINDER COMP. Cylinder gasket	1 D131491- 1 I -E235500
1-005 1-007 1-008	017-06091-201 041-00000-200 039-06100-200		1 E235501-
1-009 1-009	031-06097-200 031-06097-201	PISTON PISTON	2 1 I -D178755 1 D178756-
1-010		CRANK SHAFT COMP.	1
1-014 1-015 1-016	999-66122-266 072-0632R-900	BALL BEARING #6001, 28MM/OD OIL SEAL 12227 CRANK CASE ASS'Y	2 2 .
1-017 1-021	999-62071-127 810-06000-201	NEEDLE BEARING F-79 Recoil starter gasket	1 1 D E235501-
1-023 1-024 1-024	330-00200-210	VOOD-RUFF KEY 3X13X4.5 GEAR SHAFT SHIN 0.10 GEAR SHAFT SHIN 0.15	1 V V
1-024 1-024 1-027	330-00200-230 330-00200-240	GEAR SHAFT SHIN 0.20 GEAR SHAFT SHIN 0.30 CRANK CASE GASKET	V V
1-027	090-06000-202	CRANK CASE GASKET	1 R -C219219 1 C219220-
1-029 1-030 1-031	167-20745-801 203-10000-200	PRIMARY CORD GROWHET Ignition coil comp. Primary cord grownet	
1-032 1-067	155-21702-800 990-11050-301 	HAGNETO ROTOR COMP. SCREW 5X30	
1-068 1-074 1-074	992-10050-012 990-11040-181 990-11040-221	SCREW 4X18	4 2 2 W
1-075 1-076 1-077	992-10040-012 065-00000-200		
1-078	992-00040-011	SMALL WASHER 4	2
1-089 1-090	990-11050-161 992-10050-012		4 4

FIG.2 ENGINE COMPONENTS








/	NBR		/// \$
REF	NBR PARNER	PARNAME	STR SERVINER REMARKS
2-001 2-001 2-002 2-005,1 2-005,1	738-0632R-200 738-0632R-201	NUFFLER PROTECTOR NUFFLER PROTECTOR CYLINDER COVER COLLAR HEAT SHIELD HEAT SHIELD	1 R -C171272 1 C171273- 1 R 1 R -C171272 1 -D044240 1 P -E068190
2-005 2-005 2-006 2-007	404-0602K-200	HEAT SHIELD HEAT SHIELD INLET WANIFOLD GASKET CARBURETOR INSULATOR	1 R - E068190 1 R - E235500 1 E235501 - 1 - D151567
2-008 2-009 2-009 2-010,1 2-010 2-011	599-0602K-200 599-0602K-200 178-0602K-800 173-01620-800	CUSHION RUBBER	1 N D151568- 1 N C219220- 1 D E235501- 1 -D151567 1 N D151568-
2-015 2-016 2-017 2-018 2-019 2-020	357-00601-200 348-0602R-200 342-00501-204 290-00501-802 359-02103-200	STEP BOLT CLUTCH PLATE A CLUTCH SPRING CLUTCH SHOE COMP. CLUTCH WASHER B	2 2 1 2 2 2 2 2
2-023 2-024 2-030 2-035 2-037 2-050	655-06100-200 653-06000-200 991-16080-003 700-03005-150 598-06020-900	FUEL TANK CUSHION RUBBER FUEL TANK BRACKET NUT 8 (L.H. THREAD) FUEL PIPE 3X5X150 PUNP FILTER ASS'Y	4 1 1 1 1 1
2-050 2-055 2-066 2-072 2-080 2-081	595-0062A-901 591-0602K-200 592-06666-901	TANK CAP ASS'Y FUEL TANK PET-COCK ASS'Y Clutch Washer B Screw 4x12	
2-082 2-083 2-084 2-085 2-088 2-088	992-01040-011 990-11050-121 992-10050-012 992-01050-011 990-11050-141 992-10050-012	SCREV 5X12 S.VASHER 5 VASHER 5 SCREV 5X14	1 1 1 3 3
2-090 2-090 2-091 2-092 2-093 2-096	$992 - 01050 - 011 \\992 - 00050 - 011 \\990 - 11050 - 181 \\992 - 10050 - 012 \\992 - 01050 - 011 \\990 - 11050 - 011 \\990 - 11050 - 141$	SMALL VASHER 5 SCREW 5X18 S.VASHER 5 VASHER 5	3 H 3 1 1 1 1 1
2-097 2-106 2-107 2-108 2-150 2-151	992-10050-012 992-00050-011 990-11050-421 992-10050-012 990-11050-751 992-10050-012	SMALL WASHER 5 SCREW 5X42 S.WASHER 5 SCREW 5X75	1 2 2 2 2 2 2
2-152 2-153 2-154 2-155 2-156 2-156 2-157	990-11050-121 990-11050-161 990-23050-206 992-10050-012	SHALL WASHER 5 SCREW 5X12 SCREW 5X16 H.T. BOLT 5X20 S.WASHER 5	2 2 4 1 1
2-160 2-161 2-181	992-10050-012 992-10050-012 680-06020-900 cont'd —	S.WASHER 5 S.WASHER 5	2 4 1

•

- To be cont'd -


REF. NBR PARNER	PARTNAME	STY SERIANBR REMARKS
2-185,1 2-185,1 112-0602K-200 2-185,1 112-0602K-201 2-185,1 112-0602K-201	FAN CASE Fan Case	1 -D151567 1 P -D151863 1 W
	FAN CASE FAN CASE SET	1 R -D217600 1 M D217601- 1 1 1
	BENT WASHER 8 SCREW 4X16	1 1 1 2 2 - D151567 1 N D151568-
2-206 431-0602K-200	S.WASHER 4 CARBURETOR GASKET AIR CLEANER GASKET CORD CLAMP ASS'Y	2 -D151567 1 D151568- 1 1 1 1 -C191805
2-211 740-06028-201 2-212 739-06028-200 2-213 722-06028-800 2-214 717-06028-200	CORD PROTECTION VINYL NUFFLER COLLAR NUFFLER COUPLING GASKET NUFFLER PARTITION PLATE COMP. NUFFLER BODY B NUFFLER ASS'Y V/ARRESTER	1 N C191806- 2 2 1 1 1 1
2-221 324-33900-200	GEAR CASE WASHER	1 N D217601-

FIG.3 RECOIL STARTER




REF	NBR PARNER	PARNAME		¢	SERVANER REMARKS
3-000	762-0602K-900	RECOIL STARTER BODY ASS'Y	1	1	-E235500
3-000		RECOIL STARTER BODY ASS'Y			E235501-
		RECOIL STARTER BODY			-6235500
 3-001,1	772-0601K-210	RECOIL STARTER BODY		n I	-E278205
		RECOIL STARTER BODY RECOIL STARTER BODY COMP.		R	-E278205 E278206-
3-001	112-00018-000	RECUIL STAKIER BUDI COMP.	[¹]		6278200-
3-002	760-06002-200	STARTER ROPE REEL	1		
3-002	779-06092-200		lil	M	
3-003	779-01250-200		lil		
3-004	788-06092-200		lil		
3-005		FRICTION PLATE			
3-006	836-01250-200	FRICTION SPRING	11	H	
3-008	836-06092-200	FRICTION SPRING	1		
3-009	783-06092-200	ROPE 3.5X890L	1		
3-010	832-06092-200	RETURN SPRING	1		
3-011	782-06097-200		1		-E235500
3-011	782-0602K-200		1	N	E235501-
3-012	785-06097-200	STARTER HANDLE	1		
3-013		STARTER HANDLE CAP			5005500
3-014	990-15050-121			11	-E235500
3-014	990-15050-126	SUKEW SX12		N	E235501-

FIG.4 AIR CLEANER



REF. NBR REMARKS SERIANBR PARNAME PARNER C 410-0602D-901 AIR CLEANER ASS'Y 4-000 1 410-0602B-901 AIR CLEANER ASS 424-0602K-200 AIR CLEANER CAP 424-0602K-201 AIR CLEANER CAP 446-0602K-200 CLEANER ELEMENT 453-0602K-200 SPACER 470-0602K-200 COLLAR 4-001 R -E235500 1 1 4-001 E235501-4-002 1 2 4-003 4-004 528-0602D-200 CHOKE PLATE, W/2NN HOLE 423-0602K-200 CLEANER BODY 423-0602K-210 CLEANER BODY 4-005 1 4-006 1 -E235500 4-006 N 1 E235501-


FIG.5 CARBURETOR



1 4 4

REF.NB	PARTIER PARTIER	PARNAME		TR SERIANBR REMARKS
5-000 45 5-000 45 5-001 53 5-001 53	5-25101-900	CARBURETOR ASS'Y CARBURETOR ASS'Y, WY-6B SWIVEL SWIVEL	1 R 1 R 1 R 1 R 1 M 1 M	-D204250 D204251- -D151567
5-003 54 5-004 51 5-005 61 5-006 61	4-25100-200 4-25100-200 3-25100-200	STOP RING ADJUSTER STAY THROTTLE SET SCREW CABLE ADJUSTER CABLE ADJUST NUT IDLE ADJUST SCREW	1 1 2 1 1 1	- D 1 5 1 5 6 7
5-008 46 5-009 48 5-009 48 5-010 43	3-25100-200 8-25100-800		1 P 1 1 1 N 2 1	-0204250
5-012 59 5-012 59 5-012 59 5-013 57	9-25100-244 9-2000W-440 7-25100-200	MAIN JET #44 Main jet #44 Main jet #44	1 M 1 H 1 M 1 N 1	-D204250
5-015 52 5-016 52 5-017 57 5-018 57	8-25001-200 5-25100-800		1 R 1 1 1 1	-D151567 D151568- -D204250 D204251-
$\begin{array}{cccccccc} 5-019 & 47\\ 5-020 & 47\\ 5-021 & 47\\ 5-021 & 47\\ 5-021 & 47\\ 5-022 & 54\end{array}$	25-25001-200 24-25001-800 26-25006-200 26-25004-200 8-25101-200	DIAPHRAGM GASKET NETERING DIAPHRAGN COMP. DIAPHRAGN COVER DIAPHRAGN COVER	1 1 1 1 4 1	
		THRUST VASHER	1 1	
		·.		

FIG.6 DRIVE SHAFT & HANDLE



REF	NBR PARNER	PARTUANE	STY SERANBR REMARKS
6-002 6-003.1 6-003 6-003 6-003 6-004	504-33700-201 870-33703-900 870-33005-900 870-33005-901	SHAFT GRIP THROTTLE LEVER ASS'Y THROTTLE LEVER ASS'Y THROTTLE LEVER ASS'Y STOP BUTTON COMP.	1 1 1 1 1 1 1 1 2 1 1 1 1 1 1 1 1 1 1 1 1 1
6-005,1 6-005 6-006 6-007 6-008 6-008 6-008	500 - 33700 - 203 500 - 33006 - 800 992 - 01080 - 011 640 - 33005 - 200 115 - 33210 - 200 115 - 33210 - 202	HANDLE COMP. WASHER 8 STOP BUTTON BRACKET BRACKET	1 R -E235500 1 E235501- 1 D D151568- 1 D D151568- 2 M 2 D D151568-
6-009 6-010 6-011 6-012 6-013 6-015	990-21060-501 359-02103-200	HEX. NUT 4 STOP CORD COMP.	1 D D151568- 1 D D151568- 1 N D151568- 1 N D151568- 1 1 1 1
6-016 6-017 6-017 6-018 6-019 6-019	$\begin{array}{r} 341 - 33005 - 810 \\ 341 - 33006 - 810 \\ 350 - 33006 - 800 \\ 344 - 33005 - 210 \end{array}$	DRIVE SHAFT PIPE ASS'Y DRIVE SHAFT PIPE COMP. DRIVE SHAFT PIPE COMP. FLEXIBLE LINER COMP. FLEXIBLE SHAFT FLEXIBLE SHAFT	1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1
	441-33005-201 441-33006-800 442-33006-200 442-33005-200		1 R -C219219 -D151567 1 N D151568- -D151567 2 W 2 D151568-
6-022 6-023 6-023 6-024 6-025 6-025 6-026	760-33005-200 370-33005-210	S.WASHER 6 BOLT 6X15 BOLT 6X15 W/PLUS SPECIAL WASHER CUTTER CASE COVER CUTTER HOLDER	2 2 2 2 2 2 2 2 2 2 2 1 151567 2 151568- 1 1 1 1 1 1 1 1 2 2 2 2 2 2 2 2 2 2 2 2 2
6-028 6-029 6-030 6-031 6-036 6-037	316-33005-200 992-29080-000		1 N E235501- 1 N E235501- 1 N E235501- 1 N E235501- 2 D D151568- 2 D D151568-
6-038 6-038 6-041 6-042 6-043 6-043	444-33005-200 880-33564-200	RETURN SPRING STOP SWITCH	1 H 1 D D151568- 1 N D151568- 1 N D151568- 1 N D151568- 1 N D151568- 1 -E235500
$\begin{array}{c} 6-043\\ 6-044\\ 6-045\\ 6-045\\ 6-046\\ 6-047\\ 6-048\\ \end{array}$	$\begin{array}{r} 176-33564-200\\ 956-33564-200\\ 958-33564-200\end{array}$	STOP SWITCH STOP SWITCH SPRING EARTH TERMINAL LOCK BUTTON A LOCK BUTTON SPRING LOCK BUTTON B	1 N E235501- 1 N D151568- 1 N D151568- 1 N D151568- 1 N D151568- 1 N D151568- 1 N D151568- 1 N D151568-
$\begin{array}{c} 6 - 0 \ 4 \ 9 \\ 6 - 0 \ 5 \ 0 \\ 6 - 0 \ 5 \ 1 \\ 6 - 0 \ 5 \ 7 \\ 6 - 0 \ 5 \ 7 \\ 6 - 0 \ 5 \ 7 \\ 6 - 0 \ 5 \ 7 \end{array}$	994-31050-301 994-31050-251 991-86050-000 990-11040-161 990-11040-121 990-11040-121	SCREW 5X25 SELF-LOCK NUT 5 SCREW 4X16 SCREW 4X12	2 N D151568- 1 N D151568- 3 N D151568- 2 R -C219219 2 C219220- 2 D D151568-
6-058 6-059 6-059		WASHER 4 Cord Cutter Blade Cord Cutter Blade	2 D D151568- 1 I -C219219 1 C219220-

- To be cont'd -

.

•

	REF	NBR PARTIER	PARNAME	ST SERANBR REMARKS
	6-059 6-060 6-060	800-33005-201 799-33005-200 799-33005-200	CORD CUTTER BLADE BLADE GUIDE BLADE GUIDE	1 D D151568- 1 N C219220- 1 D D151568-
	6-061 6-062 6-064	991-01040-011 992-10040-012 371-33005-200	HEX. NUT 4 S.WASHER 4 CUTTER SHAFT SPACER	2 D C219220- 2 D C219220- 1 D E235501-
-				
	:			

•

FIG.7 TOOLS & NYLON HEAD





FIG.8 MARKS







1

CAUTION

TO AVOID POSSIBLE INJURY, GUARD MUST BE IN PLACE DURING OPERATION. FOR SAFE USE, FOLLOW INSTRUCTIONS IN OWNER'S MANUAL EYE PROTECTION SHOULD BE WORN BY USER OF THIS UNIT.

--- 3



 \overline{a}