

Blower / Vac

Model: THB-2100

DPL-BV210-HST 01-10-96

THB-2100 OPTIONS AND ACCESSORIES

MANUALS / CATALOGS

211672 Owner's Manual DPL-PE210-HST Parts Catalog



700109 2.8 oz. Bottle, 1 Gallon Size (24*) 700108 16 oz. Self-measuring Bottle (24*) 700110 1 Gallon Jug Commercial Size (6*) * Case Quantity

SPECIAL TOOLS


215432 Pressure Test Tool 217720 Torx Drive Set 222785 T-25 Torx Drive 3.5 009-29323-500 Piston Pin Remover

111124 T-27 Torx Drive 3.5" 323330 Ignition Tester 91424 Tachometer





POWERHEAD ASSEMBLY



THB-2100 PARTS LISTING

REF.	PART NO.	PART DESCRIPTION	Q	С	S	SERIAL NO	REMARKS
1	217669	SCREW, M4X25	2		Ċ		
2	215988	COVER, AIR CLEANER	1		D		
3	217376	FILTER, AIR	1		D		
4	216585	NUT, LOCK	2		С		
5	215993	SPACER	1		D		
6	223730	KIT, CHOKE ASS'Y			D		
7	~~~	* SHUTTER, CHOKE LEVER	1				
8	219016	SPRING, SHUTTER	1		С		
9	~~	* PLATE, CHOKE SHUTTER			_		
10	216591	WASHER	1		С		
11	216108	CLEANER, AIR	1		D		
12	215992	GROMMET	1		D		
					-		
13	224143-01	CARBURETOR, ASS'Y	1		С		SEE FIG. 4
14	224148	GASKET, CARB.			c		
15	223985	INSULATOR, CARB.			č		
16	224149	SHIELD, INSULATOR			č		
17	222481	STUD	2		c		
18	300631	KIT, MUFFLER COMP.	1		č		
.	220001				Ĭ		
19	300632	BODY, MUFFLER	1		С		
20	322018	SCREEN, SPARK ARRESTOR			c		
21	322019	PLATE, DEFLECTOR			c		
22	323829	GASKET, MUFFLER	2		c		
23	235642	NUT	2		č		
24	222480	STUD, MUFFLER	2		D		
-			~		-		
25	218652-01	SHIELD, MUFFLER	1		С		
26	216022	SCREW, M4X21.4	3		č		
27	301355	STARTER, ASS'Y			č		
28	301356	HOUSING, STARTER			č		
29	219585	SPACER, STERTER HOUSING	3		c		
30	218932	GUIDE, ROPE	1		č		
		,			-		
31	222800	SCREW, M4X9.5	1		D		
32	216590	WASHER, FLAT M4	1		c		
33	301252	DRUM, ROPE ASS'Y	1		c		
34	216093	ROPE, STARTER			D		
35	300474	SPRING, STARTER			c		
36	218941	WASHER, NYLON			D		
					-		
37	216792	HANDLE, STARTER	1		D		
38	217382	CUSHION, TANK	1		c		
39	219901	TANK, FUEL	1		c		
40	219899	HOSE, FUEL INLET	1				
41	216985	PICKUP, FUEL	1		С		
42	219897	HOSE, FUEL RETURN	1		С		
A							


* Indicates the part is included in a kit or assembly and is not available individually. Q=Quan. used C=Interchangeability S=Stocking code: A=Fast moving B=Med. fast move C=Med. move D=Slow move E=N.L.A. F=Superceded or replaced by a new part. FIGURE 1 cont.

THB-2100 PARTS LISTING

REF.	PART NO.	PART DESCRIPTION	Q	С	S	SERIAL NO.	REMARKS
43	301376	KIT, FUEL CAP/DECAL	1		A		
44	211242	DECAL, "OPEN SLOWLY"	1		D		
45	322250	DECAL, FUEL CAP	1		D		
46	217390	CUSHION, TANK	1		C		
47	213178	SCREW, M5X8.5	1		D		
48	218649	WIRE, GROUND	1		D		
49	218586	COVER, CYLINDER	1		C		
50	62345	PLUG, SPARK DJ8J	1		C		
51	217320	SCREW, M6X18	2		D		
52	224448	KIT, CYLINDER/GASKET	1		D		
53	223925	GASKET, CYLINDER	1		C		
54	223455	RING, PISTON	1		C		
55	224075	PISTON	1		D		
56	111026	RING, SNAP	2		D		
57	218275	PIN, WRIST	1		D		
58	110984	BEARING, NEEDLE	1		D		
59	216583	NUT, HEX	1		C		
60	225037	PAWL, STARTER ASS'Y	1		C		
61	301203	KIT, C'CASE/C'SHAFT/C'ROD	1		D		
62	301153	CRANKCASE, ASS'Y	1		C		
63	83859	SEAL, OIL	1		C		
64	216500	SEAL, OIL	1		C		
65	215545	GASKET, CRANKCASE	1		D		
66	213191	PIN	4		D		
67	216027	SCREW, M5X28.5	4		с		
68	301273	CRANFSHAFT, ASS'Y			c		
69	213282	BEARING, ROLLER			c		
70	216143	BEARING, BALL			c		
71	102164	KEY, FLYWHEEL	1		c		
72	215541	GROMMET	1		D		
	210041						
73	218654	SHAFT, EXTENSION	1		с		
74	219383	WIRE, SWITCH ASS'Y			c		
75	222308	FLYWHEEL	11		č		
76	216022	SCREW, M4X21.4	2		č		
77	219848	COIL, IGNITION	1		č		
78	223884	KIT, SPARK PLUG WIRE	1		c		
70	05000	DOOT DUUD					
79	95266	BOOT, PLUG			C		
80	102556	CONNECTOR	1		С		
L							

* Indicates the part is included in a kit or assembly and is not availiable individually. Q=Quan. used C=Interchangeability S=Stocking code: A=Fast moving B=Med. fast move C=Med. move D=Slow move E=N.L.A. F=Superceded or replaced by a new part.

GENERAL ASSEMBLY



THB-2100 PARTS LISTING

REF.	PART NO.	PART DESCRIPTION	Q	С	s	SERIAL NO.	REMARKS
1	322916	HOUSING, INNER, IMPELLER	1		С		
2	216022	SCREW, M4X21.4	4		C		
3	218655	DISC, DRIVE	1		C		
4	218518	IMPELLER	1		C		
5	218656	WASHER	1		C		
6	213169	NUT, M8	1		C		
7	218644	SCREW	5		c		
8	301358	HOUSING, OUTER	1				
9	216389	SCREW	1				
10	218643	SCREW	1				
11	218538	PIN, COVER	1		c		
12	218539	SPRING, COVER	1		c		
13	218939	COVER, INLET	1		С		
14	46704-56	DECAL, WARNING	1		D		
15	46704-55	DECAL, WARNING	1		D		
16	223241	SWITCH, STOP	1		C		
17	219189	LEVER, THROTTLE	1		C		
18	218667	LINK, HARNESS	2		С		
19	219954	SCREW	1		с		
20	218644	SCREW	5		C		
21	219946	SHROUD, ENGINE	1		c		
22	219174	ADAPTER, TUBE			c		
23	219172	CLAMP, HOSE	1		c		
24	219187	SPRING, LOCK, THROTTLE	1		c		
25	219188	ACTIVATOR, THROTTLE LOCK	1		c		

^{*} Indicates the part is included in a kit or assembly and is not availiable individually. Q=Quan. used C=Interchangeability S=Stocking code: A=Fast moving B=Med. fast move C=Med. move D=Slow move E=N.L.A. F=Superceded or replaced by a new part.

ACCESSORIES

FIGURE 3





FIGURE 3

THB-2100 PARTS LISTING

REF.	PART NO.	PART DESCRIPTION	Q	С	S	SERIAL NO	REMARKS
1	219173-01	TUBE, BLOWER	1		С		
2	219179	NOZZLE, ROUND	1		c		
3	218841	NOZZLE	1		c		
4	301400	VAC KIT/THB-2100	1		C		
5	218947	SCREW	4		C		
6	213169	NUT	4		С		
7	223800	FRAME, REAR	1		С		
8	223798	TUBE, SUCTION	1		С		
9	223799	TUBE, OUTER	1		С		
10	323155	BAG, ASS'Y	11		С		
11	218666	HARNESS	1		C		
12	218938	HOOK, SNAP	1		С		
		1					

* Indicates the part is included in a kit or assembly and is not available individually. Q=Quan. used C=Interchangeability S=Stocking code: A=Fast moving B=Med. fast move C=Med. move D=Slow move E=N.L.A. F=Superceded or replaced by a new part.

CARBURETOR ASSEMBLY



THB-2100 PARTS LISTING

REF.	PART NO.	PART DESCRIPTION	Q	С	S	SERIAL NO.	REMARKS
ALL	224143-01	CARBURETOR, ASS'Y	1		С		
1	~~~	SCREW, PUMP COVER	2				
2	~~~	COVER, PUMP	1				
3	~~~~	(1)(2) GASKET, PUMP	1				(1) Carb. Repair Kit
4	~~~	(1)(2) DIAPHRAGM, PUMP	1				300466
5	~~~	(1) STRAINER	1				
							(2) Carb. Gasket/Diaphragm Kit
6	~~~	SCREW, THROTTLE VALVE	1				300472
7	~~~~	VALVE, THROTTLE	1				
8	~~~	SHAFT ASS'Y, THROTTLE	1				
9	~~~	SPRING, THROTTLE	1				
10	~~~	"E" RING, THROTTLE	1				
11	~~~~	(1) SCREW, HIGH SPEED	1				
				i			
12	~~~	(1) SCREW, LOW SPEED	1				
13	~~~	SPRING, ADJUSTER SCREW	2				
14	~~~	SCREW, METERING COVER	2				
15	~~~~	RETAINER, PRIMER	1				
16	223756	BULB, PRIMER	1		C		
17	~~~~	BASE ASS'Y, PRIMER	1				
18	~~~	SCREW, BASE ASS'Y	2				
19	~~~	(1)(2) DIAPHRAGM, ASS'Y, METER					
20	~~~	(1)(2) GASKET, METER. CHAMBER	1				
21	~~~	SCREW, PIN RETAINING	1			E .	
22	~~~	(1) PIN, METERING LEVER	1				
23	~~~	(1) LEVER, METERING	1				
24	~~~	(1) VALVE, INLET NEEDLE	1				
25	~~~	(1) SPRING, METERING LEVER	1				
26	~~~	(1) NOZZLE ASS'Y CK. VALVE	1				
27	~~~	(1) PLUG, WELCH	1				
28	~~~	RETAINER, CHECK VALVE	1				
29	~~~	VALVE, CHECK	1				
	·						<u></u>