


# TP-4000 Utility Pump



Motor Housing  
Identification

Key No.	Part Number	Details
1	88492	ENGINE, TP4000
2	88502	KIT, SHAFT SEAL TP4000
3	88512	FLANGE, SUCTION TP4000
4	88522	VALVE, FLAPPER CHECK TP-4
5	88532	KIT, DISCHARGE FLANGE TP4
6	88542	PLUG, DRAIN FILL
7	88547	IMPELLER, TP4000
8	16743	PLATE, WEAR
9	16753	SEAL, VOLUTE
10	16763	PLATE, SEAL - TX2 HOUSING
11	16773	PLATE, SEAL - WKT2 HOUSING