



Model XLC04BX4 Parts List

A = Standard Equipment

O = Circuit Diagram

Item#	Part#	Description	Q'ty Unit
001	136106-9	CAPSULE ASS'Y	1
	C10 266326-2	TAPPING SCREW 4X18	1 PC.
	C20 424208-6	VALVE	1 PC.
	C30 941051-3	FLAT WASHER 4	1 PC.
	D10	INC. 2,3	
002	458939-5	BUTTON A	1 PC.
003	232485-4	COMPRESSION SPRING 5	1 PC.
004	144096-2	SWITCH PLATE COMPLETE	1 PC.
005	183M16-9	HOUSING SET	1
	C10 263005-3	RUBBER PIN 6	2 PC.
	C20 422458-7	SPONGE SHEET 55-80	2
	C30 213008-7	O RING 22.4	2 PC.
	C40 819J94-2	CAUTION LABEL	1
	D10	INC. 7,20	
006	855T18-4	XLC04 NAME PLATE	1
007	422460-0	RUBBER PLATE	2
008	620A75-5	CONTROLLER	1
010	643874-2	TERMINAL	1 PC.
011	855T25-7	XLC04 SERIAL NO. LABEL	1
012	620A77-1	SWITCH UNIT	1
013	620A76-3	LED CIRCUIT	1
014	459478-8	LENS CASE	1
015	136092-4	MOTOR ASS'Y	1
	D10	INC. 16	
016	459322-9	FAN COVER	1
017	422268-2	SPONGE SHEET 57	1 PC.
018	458467-0	STAY	1 PC.
019	199966-0	HIGH PERFORMANCE FILTER SET	1
020	183M16-9	HOUSING SET	1
	C10 263005-3	RUBBER PIN 6	2 PC.
	C20 422458-7	SPONGE SHEET 55-80	2
	C30 213008-7	O RING 22.4	2 PC.
	C40 819J94-2	CAUTION LABEL	1
	D10	INC. 5,7	
021	266429-2	TAPPING SCREW 3X16	7 PC.
A01	123539-7	FLOOR T-NOZZLE 28 BLA	1 PC.
	C10 451410-8	ROLLER	4 PC.
	C20 268208-4	PIN 3	4 PC.
	C30 424096-1	WIPER	1 PC.
A02	456586-6	SASH NOZZLE 28 BLK	1 PC.
A03	458942-6	PIPE	1 PC.
A04	459038-6	NOZZLE HOLDER	1 PC.
A05	450128-8	BATTERY COVER	1 PC. (XLC04R1BX4)
A06	***DC18RC	DC18RC FAST CHARGER	1 PC. (XLC04R1BX4)
	D10	COMPO-PARTS	
A07	BL1820B	BATTERY BL1820B SET (197257-3)	1 PC. (XLC04R1BX4)
A11	458571-5	HOLDER	1 PC.