



## Model XWT14T/Z Parts List

A = Standard Equipment

O = Circuit Diagram

Item#	Part#	Description	Q'ty Unit
1	266130-9	TAPPING SCREW BIND PT 3X16	8 PC.
002-1	191K96-9	HOUSING SET	1
	C10 263005-3	RUBBER PIN 6	2 PC.
	C20 252126-6	HEX. LOCK NUT M4-7	2 PC.
	C30 8012S6-4	CAUTION LABEL	1
	D10	INC. 38	
3	268284-8	PIN 1.5	1 PC.
4	263036-2	RUBBER PIN 5	1 PC.
5	857A16-0	XWT14 NAME PLATE	1
6	422584-2	BUMPER	1 PC.
7	412556-5	HAMMER CASE COVER	1 PC.
8	140T36-8	HAMMER CASE COMPLETE	1 PC.
9	265472-8	HEX. SOCKET HEAD BOLT M4X25	4 PC.
10	261154-0	NYLON WASHER 28	1 PC.
11	231907-1	RING SPRING 10	1 PC.
13	136223-5	ANVIL E ASSY	1 PC.
	D10	INC. 11	
14	327572-3	HAMMER	1 PC.
15	216001-0	STEEL BALL 3.5	24 PC.
16	267175-0	FLAT WASHER 24	1 PC.
17	232615-7	COMPRESSION SPRING 25	1 PC.
18	216011-7	STEEL BALL 5.6	2 PC.
19	227338-0	SPUR GEAR 22	3 PC.
20	327573-1	SPINDLE	1 PC.
21	268311-1	PIN 5	3 PC.
22	233910-8	RING SPRING 43	1 PC.
23	227337-2	INTERNAL GEAR 51	1 PC.
24	213785-1	O-RING 49	1 PC.
25	140T37-6	INTERNAL GEAR CASE COMPLETE	1 PC.
26	266490-9	TAPPING SCREW PT 2X6	3 PC.
27	652069-6	FLAT HEAD SCREW M3X6	3 PC.
28	620C64-2	CONTROLLER	1 PC.
29	629477-6	STATOR	1 PC.
30	619626-3	ROTOR	1 PC.
31	412691-9	REAR COVER	1
32	266130-9	TAPPING SCREW BIND PT 3X16	2 PC.
33	620521-2	LED CIRCUIT	1 PC.
34	455053-8	F/R CHANGE LEVER	1 PC.
35	651443-5	SWITCH C3JR-4B	1 PC.
36	643874-2	TERMINAL	1 PC.
37	140T43-1	SWITCH PLATE COMPLETE	1
	C10 8012S9-8	SWITCH LABEL	1
038-1	191K96-9	HOUSING SET	1
	C10 263005-3	RUBBER PIN 6	2 PC.
	C20 252126-6	HEX. LOCK NUT M4-7	2 PC.
	C30 8012S6-4	CAUTION LABEL	1
	D10	INC. 2	
39	424517-3	CUSHION	1 PC.
41	857A24-1	XWT14 SERIAL NUMBER LABEL	1

A01	266622-8	TRUSS HEAD SCREW M4X12	1 PC.
A02	346449-3	HOOK	1 PC.
A07	***DC18RC	DC18RC FAST CHARGER	1 PC. (XWT14T)
	D10	COMPO-PARTS	
A08	450128-8	BATTERY COVER	2 PC. (XWT14T)
A09	197283-2	BATTERY BL1850B SET	2 PC. (XWT14T)
A10	832071-7	TOOL BAG	1 PC. (XWT14T)