



Parts manual
Z3815BIA/968999282, Z3815BIA/968999360
Z4217BIA/968999280, Z4218KOA/968999281
Z4218KOA/968999359

Please read the operator's manual carefully and make
sure you understand the instructions before using the




English

MAIN FRAME




NOT SHOWN:
539 10 75-23 SEAT SWITCH

MAIN FRAME




ENGINE ASSEMBLY (15 & 17.5 HP)


BRIGGS & STRATTON
MODELS 968999280, 968999282




CASTER ASSEMBLY




CONSOLE ASSEMBLY




38" DECK ASSEMBLY




42" DECK ASSEMBLY




EZT




MOTION CONTROL




DECK LIFT



DECALS



- 539 11 11-23 (Z3815, RIGHT)
- 539 11 11-24 (Z3815, LEFT)
- 539 11 11-26 (Z4217, LEFT)
- 539 11 11-25 (Z4217, RIGHT)
- 539 11 18-39 (Z4218, RIGHT)
- 539 11 18-40 (Z4218, LEFT)



539 91 30-10 decal, warning (?)

UTILITY BOX

